



635-502 TIMING COVER



ENGLISH

For pre-2005 vehicles (except Chevrolet Blazer), install the two middle bolts using the included washers.

ESPAÑOL

Para vehículos anteriores a 2005 (excepto Chevrolet Blazer), instale los dos pernos medios usando las arandelas incluidas.

FRANÇAIS

Pour les véhicules construits avant 2005 (à l'exception du Chevrolet Blazer), installez les deux boulons du milieu à l'aide des rondelles fournies.

NEED HELP?

Please call our Technical Support team for assistance from our team of certified automotive experts.

1-866-933-2911