



**INSTALLATION INSTRUCTIONS**  
**Ford RPM Air-Gap 302 Manifold**  
**For Small Block Ford Engines**  
**Catalog #7521**

---

•**Please** study these instructions carefully before installing your new intake manifold. If you have any questions or problems, please call our **Technical Hotline** at: **1800-416-8628**, 7:00 am – 5:00 pm, Pacific Standard Time, Monday through Friday or e-mail us at **edelbrock@edelbrock.com**.

---

## **IMPORTANT NOTICE!**

---

### **USE MR. GASKET #203 INTAKE GASKETS WHEN INSTALLING THIS MANIFOLD!**

**Due to a slight lack of material on the port flanges at the bottom of the rear water outlet sealing area of your manifold, embossed (stock OEM) or Printoseal style gaskets are not recommended.**

When installing your manifold with the #203 gasket, we recommend applying a small amount of silicon around the water passages both front and rear.

**These special precautions must be taken to prevent coolant from leaking into the valley of your engine!**

THANK YOU.