



09-12 Dodge 4WD 1500 1 1/4" Body Lift

Thank you for choosing Rough Country for all your suspension needs.

Rough Country recommends a certified technician install this kit. Attempts to install this kit without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read instructions before beginning installation. Check the kit hardware against the kit contents list page. Be sure you have all needed parts and know where they go. Review tools needed list and make sure you have the tools needed to install the kit.

This kit is packaged to accommodate Dodge 09-10 Standard Bed, Crew Cab models. Please be advised that in the event that this kit is installed on a standard cab or any other combination cab and bed, all body pucks may not be used, This kit does fit all models and in these instructions a 4DR SWB vehicle installation is shown.

PRODUCT USE INFORMATION

We will not be responsible for any product that is altered. We will be happy to answer any questions concerning the design, function, and use of our products by calling 800-222-7023.

This body lift was developed using a 33x12.5x20 tire with factory wheels.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder of the vehicles unique handling characteristics. These instructions should be kept in the vehicle for its service life.

Kit Contents:

- 2-Fr Bumper Relocation Brackets
- 2-Rr Bumper Relocation Brackets
- 1-Rr Bumper Center Reloc Brkt
- 8-Cab Spacers
- 6-Bed Spacers
- 4-Bed Spacers w/ stud
- 1-Poly Bag Containing:
 - 16-3/8" x 2 1/4" Bolts
 - 32-3/8" Flat Washers
 - 16-3/8" Lock nuts
 - 2-Rr Spare Tire Winch Sleeves
 - 2-8mm x 60mm Bolts
 - 2-8mm Flat Washers
 - 6-12mm x 65mm Bolts
 - 6-12mm Flat Washers




Tools Needed:


- | | |
|----------------------|----------------------|
| Jack | 8mm Socket |
| Jack Stands | 10mm Socket / Wrench |
| Wood Blocks (2x4) | 14mm Socket / Wrench |
| Pliers | 13mm Socket / Wrench |
| Hammer | 15mm Socket / Wrench |
| Phillips Screwdriver | 16mm Socket / Wrench |
| Drill Motor | 18mm Socket / Wrench |
| 1/4" Drill Bit | 19mm Socket / Wrench |
| 1/2" Drill Bit | Hand Grinder |
| Reciprocating Saw | Clamp |

CAB INSTALLATION INSTRUCTIONS

1. Raise hood disconnect positive and negative battery cable from the battery using 10mm wrench. This is done because of airbags. Check owners manual and remove airbag fuses to prevent accidental air bag deployment.
2. Remove clips holding radiator bezel by pulling up on bezel at each clip using pliers if needed. **See Photo 1.**
3. Remove four bolts holding grill on using 10mm pull on lower part of grill to remove from truck. **See Photo 2.**



4. Remove two bolts from headlights using 10mm. **See Photo 3.** Remove clip from inner fender well to gain access to rear of headlamp. **See Photo 4.**





5. Push up on clip as seen in **Photo 5** to release the headlight.
6. Unplug all wires and remove the headlamp from the truck. **See Photo 6.** Repeat for other side.





7. Remove painted bumper cover using 10mm and 8mm socket. There are 8 bolts 1 behind each headlamp and four on bottom of bumper and 2 bolts (8mm)on inner fender well. **See Photo 7 & 8.**





8. Remove clips that attach bumper to inner fender well (4 of these). **See Photo 9.** On topside of bumper there 9 tabs that must be unclipped. **See Photo 10.** (Models with chrome bumper will not have 4 bolts on the bottom or clips on fender wells). Remove the bumper cover from the vehicle.



9. On driver side unplug and pull connector off of bumper above fog lamp. Then remove 6 nuts from bumper using 18mm wrench. (3 on each side). **See Photo 11 & 12.**




10. Undo the clips on lower fan shroud pull down and remove. **See Photo 13 & 14.**




11. Using a 10mm remove ground wire from frame on driver side. **See Photo 15.**

12. Loosen all cab body mounts. On one side of the cab only, remove the bolts using a 18mm socket. **See Photo 16.** Retain the factory hardware.




13. Using a 16mm remove nuts from body mounts. **See Photo 17.**


14. Using jack stand lift body slowly from the frame. **See Photo 18.**





15. Remove body mounts from one side of the vehicle.
16. Remove studs from them using a hammer and a wrench. **See Photo 19.** Retain two for reuse on rear.
17. Install new body spacers using supplied 3/8" x 2 1/4" bolts, washers and nuts. 2 per mount. **See Photo 20.**



18. Reinstall body bolts as shown in **Photo 21** and lower body back down on frame.
19. Proceed to opposite side and install body spacers. **Do not** tighten until both sides are finished.
20. Using 14mm wrench and socket tighten new 3/8" bolts then tighten stock body bolts using 18mm socket.
21. After all body bolts a tight reinstall ground wire on driver side using 10mm wrench.
22. On the factory bumper frame mount flatten the metal tab with hammer until its flush with outside. This is done because you will be drilling into it. **See Photo 22.**




23. Using new bumper mount as a guide, clamp in place and drill new 1/2" holes. **See Photo 23.** If needed use smaller drill bit to make a pilot hole first. Test fit bumper to make sure holes line up.
24. After holes are drilled, install new bumper mount **behind** frame mount and install bumper into new holes. Install factory nuts using 18mm wrench. **See Photo 24.**




25. Reattach fog light harness on driver side.
26. Install painted bumper cover using 8 and 10mm wrenches with factory hardware, making sure bumper fits properly.
27. Install all clips then install headlamps. Pull down on clip inside fender well to lock headlamp in place. Install factory bolts.
28. Reinstall grill and then radiator bezel.

BED INSTALLATION INSTRUCTIONS




1. Using a screwdriver remove license plate.
2. Find the spare tire tools under passenger side seat and remove spare tire from truck. **See Photo 1.**
3. Unplug trailer and lighting harness from bumper. **See Photo 2 & 3.**



4. Using 13mm and 15mm wrench remove bolts from bumper on both sides. **See Photo 4.** Retain stock hardware.





5. Remove the center bolts from bumper using 15mm socket and remove. **See Photo 5.** Retain stock hardware.
6. Remove the **6 bolts** from truck bed using 18mm socket. **See Photo 6, 7 & 8.**





7. With jack stands or another method raise bed off of frame just enough to get body spacers in. **Be sure to monitor gas fill lines and take care not to over extend.**
8. Install body spacers where factory bolts were removed. **For 4 non bolt locations**, install the supplied spacers with the pressed in pin to hold them in place. **See Photo 9.**
9. Lower bed back on to frame. Install supplied 12mm x 65mm bolts& flat washers in factory mount locations.
10. Using a 19mm tighten all bolts bed bolts.
11. Using a 13mm socket remove spare tire winch. **See Photo 10.**





12. Install the **2** supplied sleeves and 12mm x 65mm bolts & washers between the spare tire winch and the frame. **See Photo 11.** Tighten bolts using 13mm socket.
13. On the bottom of rear bumper measure 1 inch on each side of center gap and mark it. Using body saw cut pieces off ,only cut 1 inch from side. **See Photo 12.**





14. On rear bumper mounts, grind the stock pins flat on both front and back sides of the mount. **See Photo 13.**
15. Clamp the new bumper bracket in place and using the new rear bumper bracket as a guide, mark hole and drill using 1/2 drill bit. **See Photo 14.**



16. Remove the 2 clip from center of hitch using a screwdriver. **See Photo 15.**
17. Install 2 studs from front body mounts that were removed into new center bumper bracket with hammer or a socket and a hammer. **See Photo 16.**



18. Install center bumper bracket as shown using 16mm to tighten. Reinstall clips. **See Photo 17.**
19. Install bumper back onto truck using stock center bolt first but do not tighten. Make sure cut out goes around hitch.
20. Install new side bumper brackets using stock bolts. 13mm and 15mm wrenches. **See Photo 18.**
21. Make sure bumper is centered on truck. Tighten all bumper bolts.



22. Plug in trailer and lighting wiring harness. Install license plate and spare tire.
23. If factory equipped, loosen exhaust tips as shown using 13mm and move to the desired location and retighten. **Do not get tips too close to bumper. See Photo 18**
24. Reconnect battery using 10mm.

POST INSTALLATION INSTRUCTIONS

1. Check all fasteners for proper torque. Check to ensure for adequate clearance between all rotating, mobile, fixed, and heated members. Test and inspect brake system.
2. On some vehicles the front lower skirting will need to be trimmed if using certain wheel /tire combinations and with heavy offset wheels. Trim only as needed.
3. Activate four wheel drive system and check front hubs for engagement.
6. Perform head light check and adjustment to proper settings.
7. All kit components must be retightened at 500 miles and then every three thousand miles after installation. Periodically check all hardware for tightness.
8. Install "Warning to Driver" decal on sun visor.