

INSTRUCTION SHEET

2003-07 DODGE RAM 1500 5.7L HEMI 2WD (ONLY)

PART # 72590, 72593, 72596, 79590,79593 & 79596

This is a custom designed exhaust header system, designed for this particular application (s). Do not bend, bang, cut, dent, drill or heat any portion of this header! Any alteration other than those suggested in this instruction sheet will void the Hedman Lifetime Guarantee!

To prevent leaks, install your headers using Hedman Hedders exhaust gaskets <u>ONLY</u> and a spray copper gasket sealant.

BEFORE STARTING INSTALLATION:

It is necessary to raise the vehicle at least 36 inches from the ground. A floor hoist is recommended, if not available, use a hydraulic floor jack with jack stands. <u>DO NOT USE A BUMPER JACK!</u>

INSTALLATION INSTRUCTIONS:

SPECIAL NOTE: HEDMAN HEDDERS DOES NOT ENDORSE OR RECOMMEND THE REMOVAL OF ANY FACTORY EMISSIONS COMPONENTS FROM THIS VEHICLE DURING THIS INSTALLATION.

- 1. Disconnect battery to avoid damage to electrical.
- 2. Spray penetrating oil on all accessible fasteners and fittings before attempting to remove.
- 3. From below disconnect the Y-pipe from the cast iron stock exhaust manifolds and leave hanging in stock location. This will be modified later to connect to the collectors of the full length design headers using the gasketless reducers supplied with the headers.
- **4.** Remove the nuts attaching the heat shields to the factory manifolds. Then unbolt and remove the stock manifolds. When stock manifolds have been removed, remove the studs.
- 5. Using a gasket scraper, remove all carbon deposits making sure that the head surface is perfectly clean before installing the Hedman Hedders.
- 6. With gasket in place carefully install the new full length headers from below. Apply a small amount of anti-seize to the threads of the supplied header bolts.
- 7. Weld the supplied header collector reducers to the truck's exhaust system. Connect the exhaust system to the headers using the supplied bolts and nuts. Tighten evenly, making sure that the system is sealing correctly.
- 8. Inspect the entire exhaust system to ensure adequate clearance for plug wires, electrical wires, brake and fuel lines.
- 9. Connect Battery and cables.

6

10. Start engine, allowing engine to gain normal operating temperature (*the temporary black paint applied to uncoated headers will smoke and burn off*). Check for leaks. Test drive the vehicle and listen for new or unusual noises. After test drive, allow the engine to cool, then re-tighten all header flange bolts.

ENJOY YOUR HEADERS WHILE COMBINING INCREASED FUEL EFFICIENCY WITH BETTER PERFORMANCE.

SPECIAL INSTRUCTIONS!

After installing your headers it is very important that your exhaust system be suspended properly. As indicated in the drawing below you must place hangers as close to the header collector as possible. Rubber hangers should be used to allow the front of the system to flex with the engine torque. A hanger is needed before and after the muffler (s). When your exhaust system is unbolted from the header collector, it should remain suspended all by itself. Your Headers Are Not designed to support your exhaust system. Failure to follow these instructions will most likely result in cracks around the area where your primary tubes and collector are welded together, and will nullify your "Lifetime Guarantee".

ve ve ve	DO NOT WRAP YOUR NEW HEADERS! The use of thermal wraps will drastically shorten the life of your Headers, and will void the Hedman "Lifetime Guarantee".		
	Gaskets installed upside-down partially bloc properly positioned gasket aligns perfectly Collector Reducer	ck exhaust ports causing leaks and void with the port on the header. Metal Hanger Muffler	Metal Hanger
	Removal of catalytic converters and other factory a to your state's local laws. Our testing indicates per		

12438 Putnam Street • Whittier, CA 90602 • tel (562) 921-0404 • fax (562) 921-7515 website: www.hedman.com • email: techsupport@hedman.com