



TRANSMISSION ADAPTER PART# 0061

Fits 1966-Up Olds, Buick, Pontiac & Cadillac to 1963-Up Chevy, Th350, Th400, 700R4, 4L60E, 4L80E & Powerglide

INSTALLATION INSTRUCTIONS

Important! Read all instructions before you begin installation.

PART LIST

1 - Steel Adapter Plate	1 - Torque Converter Pilot Bushing	6 - 3/8" Flat Washers
6 - 5/16" Flat Washers	4 - 3/8-24 x 1" Flat Head Socket Screws	2 - 3/8-16 x 1 1/2" Hex Head Bolts
4 - 3/8-16 x 1" Hex Head Bolts		

1. Bolt adapter plate to the rear of the Olds, Buick, Pontiac and Cadillac V8 Engine using the 3/8 16 x 1" Head Socket Screws included in this kit.
2. Insert the Torque Converter pilot bushing in to the end of the crankshaft, between the converter and the flex plate. ***Torque to factory specs.***
3. Use two 3/8 or 5/16 flat washers (depending on the bolt size used) on each converter bolt between the converter and the flex plate.
4. Use the stock flex plate for the year and make of the engine.



Part# 0061