

IMPORTANT NOTE: The fuel tank on your vehicle must be vented to avoid pressure building up inside the tank. Do not attempt to install and operate an EFI system without a properly vented fuel tank.



Insert fitting with gasket, screw and washer.



Twist bolt to collapse and set bung.



Bung installed.



Install ORB fitting.



Finished installation.