



**ATTENTION:** Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

### **Chrysler Town and Country 2016–08, Dodge 2016–08, Ram 2015–12 w/ 6pin motor**

1. Using a trim tool, remove any trim pieces to gain access to screws holding the door trim panel.
2. Undo screws and remove the door trim panel. Take care to undo the door release cable, locking rod and other wiring harnesses that run to the door trim panel.
3. Remove the screws securing the window lift motor to the interior door panel and remove the motor.
4. Manually adjust the height of the window until the window clips line up with access holes in the interior panel.
5. Undo the window clips and raise the window glass.
6. Place a piece of tape over the door securing the window glass at the top.
7. Undo bolts holding the interior door panel to the door frame.
8. Carefully peel back the interior door panel, taking care not to damage any plastic components that go to other door components.
9. Undo the screws holding the window regulator to the interior door.
10. Remove the old regulator and replace with the new part.
11. Replace the interior door panel and secure the bolts holding it to the door frame.
12. Remove the tape and reinsert the window glass into the window clips.
13. Attach the motor to the door panel and secure the screws holding it in place.
14. Reattach any removed wiring harnesses, door release cable and door lock pin to the door trim panel.
15. Reinstall the door trim panel.

Disclaimer:

Even though every attempt is made to ensure this information is complete and accurate, it is impossible to account for all possible circumstances or situations. Please consult with a qualified auto technician before attempting to perform any work you are not qualified to do. Automobiles can be hazardous to work on; be sure to take all necessary safety precautions. Failure to do so may result in property damage or personal injury. Certain motor vehicle standards and performance requirements may apply to your motor vehicle (such as Federal Motor Vehicle Safety Standards by the National Highway Traffic Safety Administration). Be sure that your work is performed in accordance with such standards and that you do not disable any motor vehicle safety feature.