

60550

<u>Step 1:</u>

Plug Painless harness ECM connectors in. Thread retainer bolt into ECM while inserting the blue connector into the blue slot. Repeat procedure for red ECM connector.

Step 2:

Connect ECM programmer (not included) to DLC on the Painless harness.

Step 3:

Connect orange power wire from Painless harness to switched positive (+) 12v battery or other power source. Connect black ground wire from painless harness to negative (-) terminal on battery or other power source.

Step4:

Indicator lamp will illuminate if ECM/harness are hooked up correctly.

NOTE: PAINLESS WIRING OFFERS A TECHNICAL ASSISTANCE LINE TO ANSWER ANY QUESTIONS YOU MAY HAVE. THE NUMBER IS (800)423-9696. PHONES ARE ANSWERED MONDAY THROUGH FRIDAY FROM 8 AM TO 5 PM CENTRAL TIME, NOT INCLUDING HOLIDAYS. PLEASE LEAVE A MESSAGE IF YOU ARE UNABLE TO REACH US AND WE WILL RETURN YOU'RE CALL AS SOON AS POSSIBLE.

Painless Performance Limited Warranty and Return Policy

Chassis harnesses and fuel injection harnesses are covered under a lifetime warranty. All other products manufactured and/or sold by Painless Performance are warranted to the original purchaser to be free from defects in material and workmanship under normal use. Painless Performance will repair or replace defective products without charge during the first 12 months from the purchase date. No products will be considered for warranty without a copy of the purchase receipt showing the sellers name, address and date of purchase. You must return the product to the dealer you purchased it from to initiate warranty procedures.

Copyright © 2008 by Perfect Performance Products, LLC